

# Development and Implementation of Experimental Protocol for Steady-State and Transient SCR Kinetics

Josh A. Pihl and Todd J. Toops  
Oak Ridge National Laboratory

Vadim Strots and Ed Derybowski  
Navistar, Inc.


Gordon Parker and John Johnson  
Michigan Technological University

12<sup>th</sup> CLEERS Workshop




# Objectives

- Develop experimental protocol for SCR catalysts to determine specific rate parameters for control strategies
  - Include steady-state and transient behavior
- Obtain accurate temperature dependent data under steady-state and transient operation
  - Covering typical operating range
  - Includes activity of stored  $\text{NH}_3$




# Approach to Protocol and Model Development

Catalyst Supplier




**NAVISTAR**

- ORNL provides unique capabilities and expertise not available at Navistar
- Michigan Tech models results with input from ORNL
- Navistar implements control model for device operation



$$k_{1,k} = k_k T \exp \left[ -\frac{E_k}{RT} \right]$$



**MichiganTech**

**FEERC**  
 Fuels, Engines, and Emissions  
 Research Center



**CLEERS**




**OAK RIDGE**  
 National Laboratory

# Automated bench reactor used to evaluate core samples

- Protocol programmed into system that enables automated switching of gases and furnace control
  - Solenoid valves
  - HPLC pump for H<sub>2</sub>O introduction
- Gas Analysis: MKS FTIR
- Zeolite-based SCR catalyst
  - Evaluated at 150-600°C
    - 25°C steps for 150-250°C
    - 50°C steps for 250-600°C
  - GHSV: 60,000 - 120,000 h<sup>-1</sup>




**Core samples**




# Evaluation Protocol Developed for SCR

- CLEERS SCR focus-group has posted a steady-state SCR protocol
- Accurate models also require transient data; especially for system control
- Proposed protocol provides both transient & steady-state model parameters




# Evaluation Protocol Developed for SCR

- Pretreatment establishes consistent starting point for before making measurements
  - 30 minutes at 600°C in 10% O<sub>2</sub> and 5% H<sub>2</sub>O/CO<sub>2</sub>




# Evaluation Protocol Developed for SCR

- Cool to temperature of interest
  - Maintain flows in 10% O<sub>2</sub> and 5% H<sub>2</sub>O/CO<sub>2</sub>



# Evaluation Protocol Developed for SCR


- Measure  $\text{NH}_3$  storage capacity under rich conditions
  - Remove  $\text{O}_2$  from flow; Introduce 300 ppm  $\text{NH}_3$  with 5%  $\text{H}_2\text{O}/\text{CO}_2$






# Evaluation Protocol Developed for SCR

- Measure the  $\text{NH}_3$  oxidation behavior
  - Add 10%  $\text{O}_2$  to the existing flow of 300 ppm  $\text{NH}_3$  with 5%  $\text{H}_2\text{O}/\text{CO}_2$




# Evaluation Protocol Developed for SCR

- Measure the SCR kinetics while varying  $\text{NH}_3:\text{NO}$  ratio
  - Add 300 ppm  $\text{NO}$ , to the existing flow of 10%  $\text{O}_2$ , 300 ppm  $\text{NH}_3$  with 5%  $\text{H}_2\text{O}/\text{CO}_2$
  - Vary  $\text{NH}_3$  concentration from 240 to 360 ppm ( $\alpha = 0.8-1.2 = \text{NH}_3/\text{NO}_x$ )




# Evaluation Protocol Developed for SCR

- Measure the SCR kinetics while varying  $\text{NO}_2:\text{NO}_x$  ratio
  - Stop NO + Introduce 300 ppm  $\text{NO}_2$  to 10%  $\text{O}_2$ , and 5%  $\text{H}_2\text{O}/\text{CO}_2$
  - Flow stoichiometric  $\text{NH}_3$ 
    - 400 ppm  $\text{NH}_3$  when  $\text{NO}_2:\text{NO}_x = 1.0$ ; 300 ppm  $\text{NH}_3$  for  $\text{NO}_2:\text{NO}_x = 0.0$  and 0.5




# Expected stoichiometry of SCR reactions

- NO<sub>2</sub>-only (NO<sub>2</sub>/NO<sub>x</sub> = 1.0)



- NO + NO<sub>2</sub> case (NO<sub>2</sub>/NO<sub>x</sub> = 0.5)




- NO-only (NO<sub>2</sub>/NO<sub>x</sub> = 0.0)




# Evaluation Protocol Developed for SCR

- Measure kinetics of NO oxidation to NO<sub>2</sub>
  - Stop 300 ppm NH<sub>3</sub> flow; continue to flow 10% O<sub>2</sub>, 300 ppm NO with 5% H<sub>2</sub>O/CO<sub>2</sub>
- As NO value increases to steady-state value it is possible to calculate the reactivity of stored NH<sub>3</sub>




# Evaluation Protocol Developed for SCR

- $\text{NH}_3$  storage under lean conditions
  - Turn off  $\text{NO}$  flow; wait 10 minutes
  - Introduce 300 ppm  $\text{NH}_3$  in 10%  $\text{O}_2$  with 5%  $\text{H}_2\text{O}/\text{CO}_2$




# Evaluation Protocol Developed for SCR

- Temperature programmed oxidation/desorption of  $\text{NH}_3$  stored under lean conditions
  - Turn off  $\text{NH}_3$  flow; wait 10 minutes;
  - Ramp to  $600^\circ\text{C}$  at  $5^\circ\text{C}/\text{min}$  in  $10\% \text{O}_2$  with  $5\% \text{H}_2\text{O}/\text{CO}_2$



# Protocol reveals characteristic transient chemistry of catalyst

- Planned protocol evaluated at 150-600°C, 60k-120k h<sup>-1</sup>





# Steady-State Results


# Varying $\text{NH}_3/\text{NO}_x$ ( $\alpha$ -ratio) and T demonstrate operating range of catalyst

- Generally, expected trends observed
  - With increasing temperature:
    - $\text{NO}_x$  and  $\text{NH}_3$  conversion increase
  - With increasing  $\text{NH}_3$  dose ( $\alpha$ -ratio):
    - $\text{NO}_x$  conversion increases
    - $\text{NH}_3$  conversion decreases

## Experiment conditions:

- $\text{SV} = 90,000 \text{ hr}^{-1}$
- $\text{NO}_2/\text{NO}_x = 0$
- $\alpha = \text{NH}_3/\text{NO}_x = 0.8, 0.9, 1.0, 1.1, 1.2$
- Total  $\text{NO}_x = 300 \text{ ppm}$
- 10%  $\text{O}_2$ , 5%  $\text{CO}_2$ , 5%  $\text{H}_2\text{O}$

$\alpha = \text{NH}_3/\text{NO}_x$ :    ◆ 0.8    ■ 0.9    ▲ 1    ● 1.1    × 1.2




# NH<sub>3</sub> inhibits NO-SCR reaction at low T

- Re-plotting data as a function of NH<sub>3</sub>/NO<sub>x</sub> ratio reveals NH<sub>3</sub> inhibition
- For T ≤ 300°C, increasing NH<sub>3</sub> decreases NO<sub>x</sub> conversion
  - Indicates inhibition of NO-SCR reaction by excess NH<sub>3</sub> at low T
- Trend previously reported for zeolite-SCR
  - M. Wallin et al., J. Catal. 218 (2003) 354
  - A. Grossale et al., Catal. Today 136 (2008) 18
- Temperature of inhibition is catalyst dependent

## Experiment conditions:

- SV = 90,000 hr<sup>-1</sup>
- NO<sub>2</sub>/NO<sub>x</sub> = 0
- NH<sub>3</sub>/NO<sub>x</sub> = 0.8, 0.9, 1.0, 1.1, 1.2
- Total NO<sub>x</sub> = 300 ppm
- 10% O<sub>2</sub>, 5% CO<sub>2</sub>, 5% H<sub>2</sub>O



# NO<sub>2</sub> more reactive than NO at all T


- As expected, 1:1 mixture of NO+NO<sub>2</sub> gives best performance
  - “Fast SCR” reaction
- However, NO<sub>2</sub> more reactive than NO at all temperatures
  - “Slow SCR” reaction not observed with NO<sub>2</sub>
  - NO-only is “slowest” reaction
  - Characteristic of zeolite catalyst

A. Grossale et al. Catal. Today 136 (2008) 18

- NO<sub>2</sub>-SCR reaction only contributor to N<sub>2</sub>O formation


## Experiment conditions

- SV = 90,000 hr<sup>-1</sup>
- NO<sub>2</sub>/NO<sub>x</sub> = 0, 0.5, 1.0
- NH<sub>3</sub>/NO<sub>x</sub> = stoichiometric
- Total NO<sub>x</sub> = 300 ppm
- 10% O<sub>2</sub>, 5% CO<sub>2</sub>, 5% H<sub>2</sub>O




# NH<sub>3</sub> oxidation observed above 350°C

- NH<sub>3</sub> oxidation increases rapidly above 350°C
- Catalyst selective for N<sub>2</sub> production from NH<sub>3</sub> oxidation
  - Typically oxidized to NO over precious metals
- Model must account for losses of NH<sub>3</sub> to direct oxidation
  - but not for additional NO formation





## Experiment conditions

- SV = 90,000 hr<sup>-1</sup>
- 300 ppm NH<sub>3</sub>, 10% O<sub>2</sub>, 5% CO<sub>2</sub>, 5% H<sub>2</sub>O



# NO-oxidation peaks at 450-500°C

- NO oxidation increases with temperature up to 450°C
- Conversion decreases above 500°C
  - NO<sub>x</sub> concentrations approach equilibrium values ∴ reaction slows



## Experiment conditions

- SV = 90,000 hr<sup>-1</sup>
- 300 ppm NO, 10% O<sub>2</sub>, 5% CO<sub>2</sub>, 5% H<sub>2</sub>O



# Transient Results

# All surface $\text{NH}_3$ oxidizes or desorbs at temperatures above $400^\circ\text{C}$

- $\text{NH}_3$  storage capacity probed at two points:
  1.  $\text{NH}_3$  uptake during step change at inlet
    - Absence of  $\text{O}_2$
    - $\text{NH}_3$  stored at all temperatures
    - Storage decreases as T increases
  2. Temperature Programmed Oxidation (TPO) performed after lean  $\text{NH}_3$  storage
    - Single desorption peak centered near  $300^\circ\text{C}$
    - All  $\text{NH}_3$  released/oxidized by  $400^\circ\text{C}$
- All  $\text{NH}_3$  stored at  $T \geq 400^\circ\text{C}$  oxidized by  $\text{O}_2$  or desorbed when  $\text{NH}_3$  flow stops

## Experiment conditions

- $\text{SV} = 90,000 \text{ hr}^{-1}$
- $\text{NH}_3$  Ads: 300 ppm  $\text{NH}_3$ , 0-10%  $\text{O}_2$ , 5%  $\text{CO}_2$ , 5%  $\text{H}_2\text{O}$
- TPO: 10%  $\text{O}_2$ , 5%  $\text{CO}_2$ , 5%  $\text{H}_2\text{O}$ ,  $5^\circ\text{C}/\text{min}$  ramp







# Stored $\text{NH}_3$ not available for subsequent $\text{NO}_x$ reduction above $350^\circ\text{C}$

- NO oxidation step provides another measure of  $\text{NH}_3$  storage capacity
  - NO feed constant at 300 ppm after  $\text{NH}_3$  turned off
  - Dips in NO concentration due to conversion by stored  $\text{NH}_3$
  - Rate of stored  $\text{NH}_3$  consumption (depth of dip in NO) increases with T
- Comparison to  $\text{NO}_x$  uptake under inert conditions confirms oxidation or desorption of previously stored  $\text{NH}_3$

## Experiment conditions

- $\text{SV} = 90,000 \text{ hr}^{-1}$
- 300 ppm NO, 10%  $\text{O}_2$ , 5%  $\text{CO}_2$ , 5%  $\text{H}_2\text{O}$



# Optimization of protocol necessary

- Current research plan requires ~300 hours of catalyst evaluation
  - Planned protocol evaluated at:  
150-600°C, 30k-120k h<sup>-1</sup>, inlet NO<sub>x</sub>: 150-500 ppm
  - Eight weeks of normal workday operation
- Protocol must be optimized to aid new catalyst transitions
  - Identify most critical experiments through model parameter sensitivity analysis
  - Experiments with low sensitivity are removed from the matrix
- Efforts from this project and throughout the CLEERS community to be used help guide model optimization

# Something to think about...

- After completing a portion of the protocol some steps have been modified
  - Change needed to simplify transitions...
    - only one concentration change at a time
  - ...or to modify parameter being measured
    - “Inert  $\text{NH}_3$  storage  $\rightarrow$  TPD” instead of “Lean  $\text{NH}_3$  storage  $\rightarrow$  TPO”
  - More changes may be necessary...
- Additional transient behavior measurements may be warranted
  - Cyclic  $\text{NH}_3$  introduction may offer most realistic behavior for reactivity of stored  $\text{NH}_3$
  - Inclusion will depend on the ability of the model to fit the behavior
    - Modeling results coming soon...

# Summary

- Established an evaluation protocol providing both steady-state and transient chemistry
  - Optimized protocol will economize experiments
  - Starting point for validated CLEERS SCR protocol for transient behavior
- Several key SCR-chemistry findings
  - Stored  $\text{NH}_3$  reactivity identified specifically for reactivity to  $\text{NO}_x$  reduction
  - $\text{NH}_3$  identified as an inhibiting species at low temperatures
  - Temperature dependent  $\text{NH}_3$  storage identified

# Acknowledgements

Funding provided by

Ken Howden and Gurpreet Singh  
Office of Vehicle Technologies  
Advanced Combustion Engine  
U.S. Department of Energy

